

FIG. 4





FIG. 5






FIG. 7




FIG. 8A




FIG. 8B




FIG. 8C




FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14A




FIG. 14B The card reader-writer reading the **S1420** parameters for establishing the link with the ITP and the user's authentication information from the smartcard inserted by the user, and sending them to the CPU \$1425 The CPU requesting for linking with the ITP by sending data read out to the ITP S1430 Upon the request, the ITP unauthorized determines if the user is authorized authorized The ITP establishing the connection S1435 with the telephone switch, the telephone switch waits for sending or receiving IP call. **S1432** Returning rejection information

End

FIG. 15A




FIG. 15B




FIG. 16




FIG. 17

